Reader default code ObdII

Reference : AC 5247



Item name	Reader default code ObdII
Bar code	3700461494390
Introduction	Reads and deletes most basic fault codes (engine faults, pollutant emissions). Allows real-time control of ECU values.
Text	Uses the vehicle's battery as a power source, so no internal battery is required
Specifications	Specifications : - works on most vehicles (from 2001 (petrol) and 2003 (diesel) for European vehicles, and 1996 for American vehicles) compatible with OBD2 and CAN - retrieves vehicle information (based on VIN number), the device will work as long as the vehicle manufacturer has given access to the diagnostic information - reads and clears generic and manufacturer-specific diagnostic trouble codes (DTCs) - turns off the Engine light (MIL) - supports multiple fault code requests, including general, manufacturer-specific and pending codes - on-screen code definitions - live fault code reading - determines cause of Check Engine Light (MIL) - easy-to-use with detachable OBD2 cable - works safely with vehicle ECU - reliable, safe and conveniently sized - easy-to-read 2" TFT color display - multi-language: EN, FR, DE, ES, IT, PT, FN, NL

- dimensions: 124x72x18mm
- weight: 180g

Warranty period 2 years

Tariff code Tariff Normal (TN)

Warranty Procedure DIAGNOSTIC



CLAS EQUIPEMENTS
83, chemin de la CROUZA
73800 CHIGNIN
France

Tel : +33 (0) 4 79 72 62 22
Fax :

Monday to Friday - From 8 to 12h and from 13h30 to 17h30 (16h30 on Friday)