

OE 0052

ENROULEUR ELECTRIQUE 3x1,5mm² 20m WORKSHOP CABLE REEL 3x1.5mm² 20m



ATTENTION

Avant de retourner ce produit pour quelque raison qu'il soit (problème d'installation, consignes d'utilisation, panne, problème de fabrication...), merci de nous contacter.

Contact :

Vous pouvez nous joindre par mail à sav@clas.com ou bien au 04 79 72 92 80 ou encore vous rendre directement sur notre site clas.com

Si vous avez changé d'avis concernant votre achat, veuillez retourner ce produit avant d'essayer de l'installer.

WARNING

Before returning this product for any reason (installation problem, instructions for use, breakdown, manufacturing problem...), please contact us.

Contact :

You can reach us by mail sav@clas.com or by phone +33(0)4 79 72 69 18 or go directly to our website clas.com

If you have changed your mind regarding your purchase, please return this product before you attempt to install it.

CARACTERISTIQUES

Tension : 230V ~ 50Hz

Puissance maximale : 2300W (Câble déroulé), 1000W (Câble enroulé)

Classe de protection : IP44 (Utilisation à l'intérieur)

Câble : 20m - H07RN-F - 3G - 1.5mm²

UTILISATION

- Installer et fixer l'enrouleur sur un support plan. S'assurer que l'espace autour de l'enrouleur soit suffisant pour permettre le mouvement rotatif.
- Connecter l'appareil à l'alimentation électrique, la LED "POWER" doit s'allumer.
- Tirer sur l'extrémité du câble, dérouler la longueur nécessaire et relâcher légèrement le câble pour bloquer l'enrouleur automatique.
- À la fin de l'utilisation, tirer légèrement sur le câble pour permettre le déblocage de l'enroulement automatique. La force de rappel du ressort le fera revenir dans sa position initiale.

PROTECTION THERMIQUE

Par mesure de sécurité, ce type d'enrouleur est équipé d'un disjoncteur thermique.

Dans le cas d'une coupure circuit due à une surchauffe, procéder comme suit :

- Débrancher l'alimentation du dérouleur.
- Le laisser revenir à la température ambiante. Appuyer sur le bouton rouge pour le réarmer.
- Rebrancher l'alimentation, la LED "POWER" doit s'allumer.

PRÉCAUTIONS

- L'enrouleur doit être installé sur une base rigide, fixé correctement et à proximité d'une prise électrique.
- L'enrouleur doit être utilisé à l'intérieur, et rester hors de portée des enfants.
- Si vous n'entendez pas le "clic" lors de l'enroulement, remettez le câble à l'intérieur manuellement afin de le bloquer.
- Accrocher l'extrémité du câble afin d'éviter tout risque de rembobinage involontaire et donc de blessure.
- Ne jamais dépasser la charge maximale pendant l'utilisation.
- Ne jamais ouvrir l'enrouleur.
- Accompagner le câble durant le rembobinage, ne pas essayer d'enrouler le câble manuellement.
- Pour toute réparation, contacter le revendeur.

CHARACTERISTICS

Tension: 230V ~ 50Hz.

Maximum power: 2300W (the cable is unrolled), 1000W (the cable is not unrolled).

Protection class: IP44 when using outdoor.

Cable: 20m, H07RN-F 3G - 1.5mm²

USE

- Set up and fix the cable reel on a support (wall or floor). Make sure that there is enough space around the cable reel to allow a rotary movement.
- Connect the device to the power supply; the LED "Power" should turn on.
- Pull on the cable end and unroll the necessary length. During this process, the cable reel makes "click" sounds. After you pulled on the necessary length, gently loosen the cable, it will lock the automatic rolling up.
- Once you finished, gently loosen on the cable to allow the automatic rolling up to unlock. The return spring strength will make it return to its normal place.

THERMAL PROTECTION

For security reasons, this kind of cable reel is equipped with a thermal circuit breaker. In case of circuit power cut due to overheating, follow these steps:

- Unplug the cable reel power supply.
- Let it cool down at room temperature. Press on the first red button to reset the circuit.
- Plug in again to the power supply, the LED "Power" should turn on.

CAUTIONS

- The cable reel has to be on a solid base, correctly fixed and near a receptacle.
- The cable reel has to be used indoor, keep it out of reach of children.
- If you do not hear the "click" sounds when you are unwinding the cable, put back the cable inside with your hands to lock its position.
- Hook on the end of the cable to avoid that its rewind involuntarily, which could cause injuries.
- Do not exceed the maximum load when using the machine.
- It is important to hold the cable when you are rolling it up to avoid any injury due to a quick rewinding process. Please do not try to manually roll up the cable.
- After many use, it is possible that the cable does not roll up correctly; you will then have to unwind it completely and then rewind it.
- If the cable or any other part of the cable reel is damaged, you will have to make it repair by a professional. If the entire machine is damaged, you should throw it away.



CLAS Equipements

ZA de la CROUZA
73800 CHIGNIN
FRANCE

Tél. +33 (0)4 79 72 62 22
Fax. +33 (0)4 79 72 52 86

OE 0052

ENROULEUR ELECTRIQUE 3x1,5mm² 20m

WORKSHOP CABLE REEL 3x1.5mm² 20m

Si vous avez besoin de composants ou de pièces, contactez le revendeur
En cas de problème veuillez contacter le technicien de votre distributeur agréé

If you need components or parts, please contact the reseller.
In case of problems, please contact your authorized technician.