

## Helper arm

Reference : DM 1100



<b>Item name</b>	Helper arm
<b>Bar code</b>	3700461458811
<b>Introduction</b>	Pneumatic bead lifter and pusher with articulated bead lifter arm. Rotating arm adjustment to suit all types of rims and tires. Additional roller for easy positioning of dismounting tool (Run Flat tire).
<b>Specifications</b>	Pneumatic control Adjustable articulated pressure arm for easy bead positioning Upper bead breaker roller for 4x4 and run-flat tires Support cone for inner-bead positioning Rotating thrust disk for easy removal of 2nd bead 3 storage compartments
<b>Warranty period</b>	2 years
<b>Tariff code</b>	Tariff Equipment (TE)
<b>Warranty Procedure</b>	DIAGNOSTIC

2  
WARRANTY



TE

CLAS EQUIPEMENTS  
83, chemin de la CROUZA  
73800 CHIGNIN  
France

Tel : +33 (0) 4 79 72 62 22  
Fax :

Monday to Friday - From 8 to 12h  
and from 13h30 to 17h30 (16h30 on  
Friday)