Helper arm

Reference : DM 1100



Item name	Helper arm
Bar code	3700461458811
Introduction	Pneumatic bead lifter and pusher with articulated bead lifter arm. Rotating arm adjustment to suit all types of rims and tires. Additional roller for easy positioning of dismounting tool (Run Flat tire).
Specifications	Pneumatic control Adjustable articulated pressure arm for easy bead positioning Upper bead breaker roller for 4x4 and run-flat tires Support cone for inner-bead positioning Rotating thrust disk for easy removal of 2nd bead 3 storage compartments
Warranty period	2 years
Tariff code	Tariff Equipment (TE)
Warranty Procedure	DIAGNOSTIC

2 WARRANTY TE

CLAS EQUIPEMENTS
83, chemin de la CROUZA
73800 CHIGNIN
France

Tel : +33 (0) 4 79 72 62 22
Fax :

Monday to Friday - From 8 to 12h and from 13h30 to 17h30 (16h30 on Friday)