Strobe light

Reference : AC 5038



Item name	Strobe light
Bar code	3700461485688
Introduction	The strobe lamp is connected to a candle wire via an induction sensor. It produces a flash synchronized with the ignition point. This powerful flash, directed at the ignition marks engraved on the crankshaft pulley or flywheel, "freezes" the position of these marks in relation to the fixed index, making it easy to check whether the ignition advance setting is correct or not. The exact ignition point can therefore be set with great precision.
Text	Please note that this lamp cannot be used to adjust the phase shift.
Specifications	CAUTION: The exact parameters for setting the Engine's ignition timing can usually be found in the manufacturer's technical manual.
Warranty period	2 years
Fuel type	Gasoline
Voltage	12V
Tariff code	Tariff Normal (TN)
Warranty Procedure	EASY



CLAS EQUIPEMENTS
83, chemin de la CROUZA
73800 CHIGNIN
France

Tel : +33 (0) 4 79 72 62 22
Fax :

Monday to Friday - From 8 to 12h and from 13h30 to 17h30 (16h30 on Friday)